

Lecture 19. Wind Lidar (1)

- ❑ Motivations to measure global wind
- ❑ How to measure wind ?
- ❑ Review of techniques for wind measurements
- ❑ Direct Motion Detection Technique
(Tracking aerosol/cloud motion, LTV, LDV)
- ❑ Coherent Detection Doppler Wind Technique
- ❑ Direct Detection Doppler Wind Technique
(Atomic absorption lines, Edge filters, Fringe imaging)
- ❑ Summary

Motivations for Wind Measurements

❑ **Global atmospheric wind profiles** from ground to 120 km are important for validation of the output of global atmosphere models, and for study of the atmosphere dynamics, as wave information can be inferred from the wind measurements.

❑ **Temperature** measurements are mainly for science-oriented purpose - model validation and climate change monitoring. But **wind/velocity measurements have much more applications in industry, environment, and defense business.** For example,

(1) Aircraft true airspeed, aircraft wake vortices

(2) Clear air turbulence, wind shear, gust fronts

(3) Air pollution monitoring

(4) Vibration of objects

(5) Laboratory, machine shop, production facility, wind tunnel

... .. etc.

Techniques for Wind Measurements

Use wind-dependent effects or use definition of wind

❑ Direct Motion Detection Technique:

(using the definition of velocity)

$$\vec{v} = \frac{d\vec{r}(t)}{dt}$$

(1) Tracking aerosol/cloud motions

(2) Laser Time-of-Flight Velocimetry

(3) Laser Doppler Velocimetry

❑ Doppler (Shift) Wind Technique: $\Delta\omega = -\vec{k} \cdot \vec{v}$ or $\Delta\omega = -2\vec{k} \cdot \vec{v}$

(1) Coherent (Heterodyne) Detection Doppler Wind Lidar

(2) Direct Detection Doppler Wind Lidar

❑ Geostrophic wind detection:

Temperature \Rightarrow Pressure Gradients \Rightarrow Geostrophic Wind

Direct Motion Detection for Wind


- ❑ Use the definition of velocity, i.e., velocity is the derivative of displacement vector
- ❑ Wind tracers are needed to track the motion, i.e., the position changes with time
- ❑ Aerosols, clouds, or smokestack plumes, i.e., any inhomogeneities in the atmosphere provide excellent tracers.

$$\vec{v} = \frac{d\vec{r}}{dt}$$

Common approaches for detecting motion remotely

- ❑ Crosswind determination by pattern correlation
 - (1) Tracking aerosols, clouds, plumes, trails by images
 - (2) Tracking Aerosol/cloud motion by lidars
- ❑ Laser Time-of-Flight Velocimetry (LTV)
- ❑ Laser Doppler Velocimetry (LDV)

Lidar Tracking of Aerosol Motions



[Sroga et al., JAM, 1980]

FIG. 1. The geometry used for lidar wind measurements. The lidar is operated at a constant small elevation angle and scanned back and forth between three closely spaced azimuth angles ϕ_1 , ϕ_2 and ϕ_3 . Range-resolved profiles of back-scattered intensity are recorded at ~ 1 s intervals for a period of 2–5 min to produce a wind measurement. Wind velocities are calculated in terms of a radial component v and a cross-path component u .

Doppler Wind Technique

- ❑ **Doppler Shift** is the apparent frequency change of radiation perceived or emitted by a particle moving relative to the source or receiver of the radiation, compared to when particle at rest.
- ❑ This phenomenon was first described by Austrian physicist **Christian Doppler** (1803–1853) for acoustic waves. It also occurs for electromagnetic (including optical) waves/radiation as well.
- ❑ If the frequency change can be measured, the relative velocity of the source with respect to the receiver can be determined. Note: the directly measured speed is the **velocity component along the line of sight of the radiation beam, i.e., the radial velocity**.
- ❑ A spectacular application of the Doppler effect was the determination of the freq shift of light emitted from distant stars or galaxies, all toward longer wavelengths (**universe red shift**), leading to our present notion of an expanding universe. Because the relative shift $\Delta f/f = V_R/c$ and distance stars move away fast, these measurements were easy to make, compared to Earth atmosphere.

Doppler Shift for Different Processes

- As we explained before (textbook 5.2.2.4), the Doppler shift for different processes (absorption/emission versus scattering) is different.
- For non-resonant scattering (aerosol, molecular, or radar),

$$\begin{array}{l}
 \text{Momentum Conservation} \quad m\vec{v}_1 + \hbar\vec{k}_1 = m\vec{v}_2 + \hbar\vec{k}_2 \\
 \text{Energy Conservation} \quad \frac{1}{2}mv_1^2 + \hbar\omega_1 = \frac{1}{2}mv_2^2 + \hbar\omega_2
 \end{array}
 \left. \vphantom{\begin{array}{l} \\ \\ \end{array}} \right\} \Rightarrow$$

$$\omega_1 = \omega_2 + \vec{k}_1 \cdot \vec{v}_1 - \vec{k}_2 \cdot \vec{v}_2 + \frac{\hbar k_1^2}{2m} - \frac{\hbar k_2^2}{2m}$$

- The Doppler frequency shift is given by

$$\Delta\omega_{scattering} = \omega_2 - \omega_1 = -(\vec{k}_1 \cdot \vec{v}_1 - \vec{k}_2 \cdot \vec{v}_2)$$

- Therefore, for forward scattering, $\vec{k}_2 \approx \vec{k}_1, \vec{v}_2 \approx \vec{v}_1$, so $\Delta\omega = 0$
- For backward scattering, $\vec{k}_2 \approx -\vec{k}_1, \vec{v}_2 \approx \vec{v}_1$, so $\Delta\omega = -2\vec{k}_1 \cdot \vec{v}_1$

Doppler Shift for Different Processes

- For resonant atomic absorption, the resonance absorption frequency for an atom at rest is given by

$$\omega_0 = (E_2 - E_1)/\hbar$$

Momentum Conservation

$$m\vec{v}_1 + \hbar\vec{k}_1 = m\vec{v}_2$$

Energy Conservation

$$E_1 + \frac{1}{2}mv_1^2 + \hbar\omega_1 = E_2 + \frac{1}{2}mv_2^2$$



$$\omega_1 = \omega_0 + \vec{k}_1 \cdot \vec{v}_1 + \frac{\hbar k_1^2}{2m}$$

- The Doppler frequency shift is given by

$$\Delta\omega_{abs} = \omega_0 - \omega_1 = -\vec{k}_1 \cdot \vec{v}_1$$

- The atomic absorption cross-section is Doppler shifted and broadened

$$\sigma_{abs}(\nu) = \frac{1}{\sqrt{2\pi}\sigma_D} \frac{e^2 f}{4\epsilon_0 m_e c} \exp\left\{-\left[\nu_o - \nu\left(1 - \frac{V_R}{c}\right)\right]^2 / 2\sigma_D^2\right\} \quad \sigma_D = \sqrt{\frac{k_B T}{M\lambda_0^2}}$$

Doppler Shift for Different Processes


- For atomic spontaneous emission,

Momentum Conservation

$$m\vec{v}_2 = m\vec{v}_3 + \hbar\vec{k}_2$$

Energy Conservation

$$E_2 + \frac{1}{2}mv_2^2 = E_1 + \frac{1}{2}mv_3^2 + \hbar\omega_2$$



$$\omega_2 = \omega_0 + \vec{k}_2 \cdot \vec{v}_3 + \frac{\hbar k_2^2}{2m}$$

- The Doppler frequency shift is given by

$$\Delta\omega_{sp} = \omega_2 - \omega_0 = \vec{k}_2 \cdot \vec{v}_3$$

- The Doppler frequency shift between the spontaneously emitted photon and incident photon is given by

$$\Delta\omega_{overall} = \omega_2 - \omega_1 = \vec{k}_2 \cdot \vec{v}_3 - \vec{k}_1 \cdot \vec{v}_1$$

- For backward spontaneously emitted photon, the Doppler shift is

$$\Delta\omega_{overall} = \omega_2 - \omega_1 = -2\vec{k}_1 \cdot \vec{v}_1, \quad \vec{k}_3 \approx -\vec{k}_1, \vec{v}_3 \approx \vec{v}_1$$

Coherent Detection Doppler Wind

- ❑ **Basic Principle:** the return signal is optically mixed with a local oscillator laser, and the resulting beat signal has the frequency (except for a fixed offset) equal to the Doppler shift due to the moving particles.
- ❑ More accurately, the Coherent Detection Doppler Wind lidar should be called "**Heterodyne**" Detection Doppler Wind lidar.




Fig. 12.6. Principle of a heterodyne-detection Doppler lidar.

LO: Local Oscillator; TE: pulsed laser transmitter; LL: Locking Loop

Coherent Detection Doppler Wind

The local oscillator laser has a frequency of f_{LO}

The pulsed transmitter has a frequency of $f_0 = f_{LO} + f_{offset}$

The return signal (Doppler shifted) has a freq of $f_{sig} = f_0 + \Delta f$

❑ The optical mixing results in frequencies of $|f_{LO} \pm f_{sig}|$, i.e., sum frequency and beat frequency.


❑ The sum frequency is well above the frequency cutoff of the detector, but the beat frequency is a low-frequency signal that can be determined with high accuracy.

$$f_{beat} = |f_{LO} - f_{sig}| = \Delta f + f_{offset}$$

❑ Aerosol scattering signal is utilized, owing to its narrow bandwidth and strong signals

❑ Accuracy: No bias in principle

❑ Precision: independent of the wind velocity



Direct Detection Doppler Wind

- ❑ **Principle:** no local oscillator is used. Instead, an optical frequency discriminator or spectrum analyzer is used to **convert the Doppler frequency shift to a change in optical intensity or power, or to intensity / power spatial distribution**, which is in turn directly detected.
- ❑ In these **direct detection (or incoherent) lidar** systems, the return optical signal is filtered or resolved into its spectral components prior to detection. Besides a narrowband lidar transmitter with stable frequency, the main efforts are placed onto the spectral resolved lidar receivers.
- ❑ The **optical frequency discriminators** include mainly three (or four) types
 - (1) Atomic absorption lines, like Na, K, and Fe Doppler lidar, using the resonance fluorescence from the entire line, not just the edge
 - (2) Edge-filters, like the transmission edge of a molecular absorption line (e.g., iodine I₂ absorption lines), or the edge of a transmission fringe of an optical interferometer (e.g., Fabry-Perot etalon)
 - (3) Fringe pattern imaging of the output of an optical interferometer.

Direction Detection Doppler Wind

□ For resonance fluorescence Doppler lidar, the **resonance fluorescence from atoms, e.g., Na, K, Fe**, in the mesosphere and lower thermosphere is utilized. The atomic absorption lines act as natural frequency analyzers.

□ Non-resonance direct detection Doppler lidars utilize **aerosol scattering, or molecular scattering, or both**.

□ The main ideas are

Intensity ratio (like in Na, K, and Fe Doppler lidar)

⇒ Frequency shift ⇒ radial velocity (LOS)

Intensity change (like in HSRL or some Rayleigh Doppler lidar)



⇒ Frequency shift ⇒ radial velocity (LOS)

Intensity spatial distribution (like in some Rayleigh Doppler lidar)

⇒ Frequency shift ⇒ radial velocity (LOS)

Freq Analyzer: Atomic Absorption Lines

□ The resonance fluorescence Doppler lidar is one kind of direct detection Doppler lidars (DDL). It has been covered in great details in previous lectures.



From intensity ratios (photon count ratios) to derive wind and temperature

Freq Analyzer: Single-Edge Filter




Figure 7.31 Single-edge functional diagram and filter transmission.

□ A Fabry-Perot etalon or a molecular absorption line is usually employed as the edge filter. The etalon is locked to the zero-Doppler laser frequency, ν_0 , such that the frequency of the transmitted laser is matched to the mid-point of the quasi-linear transmission edge of the etalon.

□ The intensity ratio of these two channels is a function of the Doppler frequency shift ν_s .

$$S = I_1/I_2 = \frac{\eta_{bs}}{(1 - \eta_{bs})} \frac{\mathfrak{R}_1}{\mathfrak{R}_2} T_s$$

$$= \frac{\eta_{bs}}{(1 - \eta_{bs})} \frac{\mathfrak{R}_1}{\mathfrak{R}_2} (T_0 - T_m \nu_s / \Delta \nu)$$

Freq Analyzer: Double-Edge Filter





Figure 7.32 Double-edge functional diagram and filter transmission.

❑ Two oppositely sloped quasi-linear discriminator edges are used for the two receiver channels in the double-edge design. Usually etalon transmission fringes are used to create the edges. The etalons are locked together (mid-point) to the zero-Doppler transmitted laser frequency ν_0 .

❑ The intensity ratio of the difference between the two signals to the sum is a sensitive function of the Doppler frequency shift ν_s .


$$S = \frac{I_{\Delta}}{I_{\Sigma}} = \frac{I_1 - I_2}{I_1 + I_2} = \frac{T_{s_1} - T_{s_2}}{T_{s_1} + T_{s_2}} = \frac{2\nu_s}{\Delta\nu}$$

Freq Analyzer: Fringe-Imaging



- ❑ The basic concept of fringe-imaging discriminator is to utilize a high-resolution interferometer to produce a spatial irradiance distribution, which is representative of the receiver-plane signal spectrum.
- ❑ The mean frequency is then estimated by one of a variety of methods, e.g., the location of the irradiance peak, and the first moment of the irradiance distribution, etc.
- ❑ Similar to passive F-P Interferometer, the diameter of the concentric rings can be used to determine the frequency shift.

Wind Techniques



- 75-120km: resonance fluorescence (Na, K, Fe)
Doppler technique (DDL)
- FPI: Fabry-Perot Interferometer
- Below 60km: Rayleigh Doppler technique (DDL)
- Below 30 km: Direct Detection Doppler technique
- In troposphere: Coherent Detection Doppler technique, Direct motion Detection technique (tracking aerosol motion), LDV, LTV

Summary

- ❑ Mainly two methods to measure true wind velocity: use the definition of velocity or use the Doppler shift effect.
- ❑ Using the definition of velocity (derivative of displacement), the direct motion detection of aerosols, clouds, or smoke plumes, by images and lidars can obtain wind with high resolution mostly in lower atmosphere or in industrial shop, lab or wind tunnel.
- ❑ Using the Doppler effect, the Doppler wind lidar can extend the wind measurements up to the lower thermosphere, using the resonance fluorescence, molecular and aerosol scattering.
- ❑ Two main Doppler wind lidars are the coherent (heterodyne) detection and direct detection Doppler wind lidars.
- ❑ The direct detection Doppler lidars use atomic absorption line, the edge filters, and fringe-imaging techniques to discriminate or analyze the frequency or spectrum of the return lidar signals (Doppler shifted).